



Circular 7 CX Circular 9 CX





INFORMATION ON SOLID FUEL HEATING APPLIANCES According to Regulation (EU) n. 1185/2015

Manufacturer	Aico	
Model identifier(s)	Circular 7 CX	
Brand	Ravelli	
Indirect heating functionality	No	
Direct heat output	6,5 kW	
Indirect heat output	kW	



web: ravelligroup.it

Fuel type	Preferred fuel (only one):	Other suitable fuel(s):	ηs [x%]				Space heating emissions at minimum heat output (*) (**)			inimum	
				PM OGC CO NOx PM	OGC	co	NOx				
					[x] mg/Nm ³ at 13%O2			[x] mg/Nm3 at 13%O2			
Wood logs with moisture content ≤ 25 %	No	No								2	
Compressed wood with moisture content < 12 %	Yes	No	84	13	1	59	94	9	2	187	145

		Onlardo	toriotico wilcir c	operating with the preferred fuel only		
Item	Symbol	Value	Unit	Type of heat output/room temperature control (select one)		
Heat output				single stage heat output, no room temperature control	No	
Nominal heat output	Pnom	6,5	kW	two or more manual stages, no room temperature control	No	
Minimum heat output (indicative)	P _{part}	3,6	kW	with mechanic thermostat room temperature control	No	
Useful efficiency (NCV as received)				con controllo elettronico della temperatura ambiente	No	
Useful efficiency at nominal heat output	η _{th,nom}	94,2	%	with electronic room temperature control plus day timer	No	
Useful efficiency at minimum heat output (indicative)	η _{th,part}	92,6	%	with electronic room temperature control plus week timer	Yes	
Auxiliary electricity consumption			Other control options (multiple selections possible)			
At nominal heat output	el _{max}	0,0242	kW	room temperature control, with open window detection	No	
At minimum heat output	elmin	0,01	kW	room temperature control, with presence detection	No	
In standby mode	elsa	0,003	kW	with distance control option	Yes	

^(*) PM = particulate matter, OGCs = organic gaseous compounds, CO = carbon monoxide, NOx = nitrogen oxides (**) Only required if correction factors F(2) or F(3) are applied



INFORMATION ON SOLID FUEL HEATING APPLIANCES According to Regulation (EU) n. 1185/2015

Manufacturer	Aico	
Model identifier(s)	Circular 9 CX	
Brand	Ravelli	
Indirect heating functionality	No	
Direct heat output	8,2 kW	
Indirect heat output	kW	



Fuel type	Preferred fuel (only one):	Other suitable fuel(s):		minal heat	Space heating emissions at minimum heat output (*) (**)			ninimum				
				PM OGC CO NOx PM		OGC	co	NOx				
					[x] mg/Nm³ at 13%O2	[x] mg/Nm3 at 13%O2						
Wood logs with moisture content ≤ 25 %	No	No										
Compressed wood with moisture content < 12 %	Yes	No	89,7	14		4	78	96	9	2	187	145

				operating with the preferred fuel only			
Item	Symbol	Value	Unit	Type of heat output/room temperature control (select one)			
Heat output				single stage heat output, no room temperature control	No		
Nominal heat output	P _{nom}	8,2	kW	two or more manual stages, no room temperature control	No		
Minimum heat output (indicative)	Ppart	3,6	kW	with mechanic thermostat room temperature control	No		
Useful efficiency (NCV as received)				con controllo elettronico della temperatura ambiente	No		
Useful efficiency at nominal heat output	П th,лот	92,2	%	with electronic room temperature control plus day timer	No		
Useful efficiency at minimum heat output (indicative)	η _{th.part}	92,6	%	with electronic room temperature control plus week timer	Yes		
Auxiliary electricity consumption				Other control options (multiple selections possible)			
At nominal heat output	el _{max}	0,024	kW	room temperature control, with open window detection	No		
At minimum heat output	el _{min}	0,010	kW	room temperature control, with presence detection	No		
In standby mode	else	0.003	kW	with distance control option	Yes		

^(*) PM = particulate matter, OGCs = organic gaseous compounds, CO = carbon monoxide, NOx = nitrogen oxides (**) Only required if correction factors F(2) or F(3) are applied

Model: CIRCULAR 7 CX Page 6,5 kW 3,6 kW P pert Psunom 6,5 kW Pswpart 3,6 kW -- kW Pwnom Pw part -- kW 94,2 % η_{nom} 92,6 % 1 part CO nom/13%029 59 mg/Nm³ COpartif1%02) 187 mg/Nm³ NOx nam(131602) 145 mg/Nm³ 94 mg/Nm³ NOx part(13502) 2 mg/Nm³ OGC nerry(13%02) OGC part (131502) 1 mg/Nm³ PM nore(13%02) 13 mg/Nm³ PM pert(13%02) 9 mg/Nm³ Prom 10 Pa Poart 10 Pa pw -- kPa (-- bar) T 200 G Tancer 115 °C Wroex 320 W E f 50 Hz 230 V Funzionamento Continuo Continuos operation Fonctionnement Continu Funcionamente Continuo (CON) ontinue Werking kontinulerlicher Betrieb d_R 200mm Distanza minima da materiali combustibili d s 200 mm Minimum distance from combustible materials d c Distance minimale par rapport aux matériaux 750 mm d_{p} 1500mm Distancia mínima de materiales combustibles 800mm d F Minimumafstand tot brandbare materialen 800mm Mindestabstand zu brennberen Materialien ď L d_B 30mm Pellet di legno Usare solo il combustibile raccomandato: Use only recommended fuel: Wood pellet Utilizer seulement les combustibles recomendés: Use sols el combustible recomended: Gebruik ellesen de sambovolen brasésion! Nur emptoblenes Brennmaterial verwenden: Gorquies de bais Pellet de roadera Houtpellet Hotspollets Ø 6 mm L'apparecchio non à adatto alfundo namento in una canna famoria condiviso / The appliance is not suitable for operation in a shared chimney / L'apparelin'est pas adapt i une utilisation dans une chemin partiage / Ellaparation de sapto para funcionar en una chima noa compartida / Not apparatit is nisti geschiet voc qu'entre in en o gedovide schoonsteen / Das Gerit ist nicht il ur den Betrieb in einem gemennamen komin geeignet. Leggere e seguire le istruzioni per l'uso i Read and follow the operating manual / Lire et suivre le mode d'emploi / Leay respete le manual de operacion / Leas en volg de handleiding voor bediening / Bitte lesen und befolgen Sie die Montage und Nutzungsanv D.o.P. nº (Notified Body 0476) EN 16510-1:2022; EN 16510-2-6:2022 Type: CM 50 Year of production: 2025 **** **RAVELLI** AICO S.r.I. - Via Consorzio Agrario, 3/D - 25032 Ohiari (BS) - Italy

14

13

Model: CIRCULAR 9 CX

1

2

3

4

5

6

7

8

9

10

11

12

15

Prom	8,2 kW	P port	3,6 kW
Ранлого	8,2 kW	Psupart	3,6 kW
Рилот	kW	Pw part	kW
Л _{. Болт}	92,2 %	η _{pert}	92,6 %
CO nom/12%02)	78 mg/Nm ³	CO part(13% 02)	187 mg/Nm ³
NOx nam(12%02)	86 mg/Nm ³	NO ₂ part(135600)	145 mg/Nm ³
OGC norn(13%02)	4 mg/Nm ³	OGC party 72% 029	2 mg/Nm ³
PM nere(131602)	14 mg/Nm ³	PM part(13%02)	9 mg/Nm ³
Pnom	9 Pa	Ppert	10 Pa
p.,	kPa (bar)	Toless	T 200 G
Tanon	137 °C	Wasex	320 W
E	230 V	f	50 Hz

Funzionamento Continuo Continuos operation Fonctionnement Continu Funcionamento Continuo (CON) Continue Werking Rontinulerlicher Betrieb

200mm d_R Distanza minima da materiali combustibili d s 200mm Minimum distance from combustible materials Distance minimale par rapport aux matériaux d_c 750mm combustibles 1500mm d_p Distancia minima de materiales combustibles d_F 800mm Minimumatstand tot brandbare materialen ď L Mindestabatand zu brennberen Materialien 800mm 30mm

Pellet di legno Usare solo il combustibile raccomandato: Use only recomended fact:
Utilizer seclement les combustibles recomendés;
Use solo el combustible recomendade;
Gebruik affect de aanbewolen brandskrit. Wood pelict Grenvine de hois Petint de medere Houtpelist Nur empfohlenes Brenomaterial verwenden: Holypollate 0 5 mm


L'apparecchie non è additio al funcionamente in una canno femoria conditiba (The appliance is not suitable for operation in a shared chimney (L'apparel n'est pas adapt à une utilisation dans une chomin partiage) (El apparel no es aprìo para funcionar en una chimene compartità / Het apparent in riet geschiet vos optimis in seno gedevicie se boorsteen (Das Gert List nicht für den Betrieb in einem gemeinamen Kamin gereignet.

Loggere e seguire le istruzioni per l'uso / Read and follow the operating manual / Lire et sulvire le mode d'emploi / Leay respete le manual de operacion / Lees en volg de handleiding voor bediening. Bitte lesen und befolgen Sie die Montage und Nutzungsanweisungen

(Notified Body 0476)

EN 16510-1:2022; EN 16510-2-6:2022

Type: CM 50 Year of production: 2025





EXPLANATION OF THE IDENTIFICATION PLATE

Type, number or model designation to identify the product

2 Table of values:

-				
	P int	Maximum input power	P int part	Partial input power
	Pnom	Nominal heat output	Ppart	Partial heat output
	PSHnom	Nominal heat output to air	P _{SH part}	Partial heat output to air
	Pwnom	Nominal heat output to water	Pwpart	Partial heat output to water
	η_{nom}	Appliance efficiency at nominal heat output	η_{part}	Efficiency of the appliance at partial heat output
	CO _{nom}	CO emissions at 13% oxygen content at nominal heat outputossigeno alla potenza termica nominale	CO _{part}	CO2 emissions at 13% oxygen content at partial heat output
	NO _{xnom}	NOx emissions at 13% oxygen content at nominal heat output	NO_{xport}	NOx emissions at 13% oxygen content at partial heat output
	OGC nom	Hydrocarbon emissions at 13% oxygen content at nominal heat output	OGC part	Hydrocarbon emissions at 13% oxygen content at partial heat output
	PM _{nom}	Particulate emissions at 13% oxygen content at nominal heat output	PM part	Particulate matter emissions at 13% oxygen content at partial heat output
	p _{nom}	Minimum flue draught at nominal heat output	p_{part}	Minimum flue draught at partial heat output
	p _{wnom}	Minimum flue draught at nominal heat output	T_{dass}	Chimney designation according to the appropriate chimney standard
	T _{snom}	Flue outlet temperature at nominal heat output	T_{fgnom}	Flue gas temperature at nominal power
	W_{max}	Maximum electrical power absorbed	E	Supply voltage
	f	Frequency		

Product operation type

4 Minimum distance from combustible materials:

d _R	Minimum distances from the rear to flammable material	200 mm
d_s	Minimum distances from the sides to flammable material	200 mm
d_c	Minimum distances from the top to flammable material	750 mm
d,	Minimum distances from the front to flammable material	1500 mm
d,	Minimum distances from the front to flammable material	800 mm
d _L	Minimum distances from the front to flammable material	800 mm
d _B	Minimum distances from the bottom (excluding the feet) to flammable material	30 mm

- Recommended fuels
- 6 Warning
- 7 Warning
- 8 Document number DOP and (Notified Body)
- 9 Applicable standards
- 10 Product classification
- 11 Year of production
- 12 Environmental classification
- 13 CE conformity mark The numbers indicate the year of issue of the certificate
- 14 Serial number
- 15 Registered trademark

Preface

Dear Customer, We would like to thank you for choosing one of our stoves.

We invite you to read this manual carefully, before starting installation and use, so that you are able to benefit from all of its characteristics better and in full safety. It contains all necessary information for correct installation, start-up, operation, cleaning, maintenance, etc.

Keep this manual in a suitable location, do not discard it without reading it.

Incorrect installation, maintenance and improper use of the product relieve the Manufacturer of all liability deriving from use of the stove.

For further information and requirements contact your Ravelli-authorised Technical Assistance Centre.

All rights reserved. No part of this instructions manual can be reproduced or transmitted through any electronic or mechanical means, including photocopies, recordings or any other storage system, for other purposes that are not exclusively use by the buyer's staff, without the express written consent of the Manufacturer.



SUMMARY

CE LABEL	4
Preface	7
IDENTIFICATION	10
Stove identification	10
Manufacturer identification	10
Reference standards	10
Remote control: Synthetic Declaration of Conformity (DoC)	10
WARRANTY	11
Warranty conditions	11
Registration of warranty	11
Info and problems	11
GENERAL INFORMATION	
Supply and safe-keeping	12
Language	
Symbols used in the manual	12
SAFETY MEASURES	
General safety warnings	
Residual risks	13
DESCRIPTION OF THE APPLIANCE	
Intended use	
Reasonably foreseeable incorrect use	
Obligations and forbidden actions	
Characteristics of the fuel	16
TECHNICAL CHARACTERISTICS	17
Technical diagram Circular 7 - Circular 9	17
Main parts	18
Minimum distance from fireproof materials	18
Description of operation	19
Automatic cleaning system	19
Recharge the fuel	20
Doors opening	
User training	20
Safety devices	21
SHIPPING AND INSTALLATION	
Safety warnings for transportation and installation	22
Set-ups for the smoke evacuation system	23
Installation	24
CONNECTIONS	27
Flue connection	27
Concentric installation	27
Upper flue gas outlet Ø80 with internal air intake	
Upperflue gas outlet Ø80 with external air intake	
Rear smoke exhaust	
Electrical connection	
Connection of external probe or thermostat	
Testing and commissioning	32
Electric scheme Circular 7 - Circular 9	32

Pag.9



CONTROLS AND USE	
Control panel description	33
Radio touch remote control initialization	33
Description of the radio touch remote control	
Description of the display	34
Time and date setting	
·	
PROCEDURES FOR USE	36
Checks prior to start-up	36
Auger loading	36
Switching the appliance on and off	36
Failed ignition	
Setting operating temperature and power:	
OPERATING PHASES OF THE APPLIANCE	
Sequence of ignition phases	
Modulation	
Description of menu functions	
Setting	
Ventilation menu (function present only for ducted and ventilated models)	42
Stove phase general layout	43
Warning Pop -Up	
Alarms (table with reference codes)	44
	4-
INSTALLATION QUICK GUIDE RAVELLI SMART WI-FI	
Connect the WiFi module cable	
App	
Connection to the WiFi module	
Account registration	49
MAINTENANCE	E4
Safety warnings for maintenance	
Cleaning	
Extraordinary maintenance	
Extraordinary maintenance	,
TROUBLESHOOTING	55
The appliance does not work	
Difficult lighting	
Smoke leakage	
The glass gets dirty easily	
Downtime (end of season)	
201110110 (0114 01 0040011)	
DISPOSAL AT END OF SERVICE LIFE	55
Warnings for the correct disposal of the product	
σ σ σ σ σ σ σ σ σ σ σ σ σ σ σ σ σ σ σ	



Rev.0 09/07/2025

Use and maintenance manual Circular

Pag.10



IDENTIFICATION

Stove identification

Type of product

Trademark

Model

Manufacturer identification

Manufacturer

PELLET STOVE

Ravelli

Circular 7 CX- Circular 9 CX

Aico S.r.I.

Via Consorzio Agrario, 3 -25032 Chiari (BS) - Italy T. + 39 030 7402939 info@ravelligroup.it www.ravelligroup.it

Reference standards

The stoves Circular 7 - Circular 9 that this manual refers to are compliant with the regulation:

305/2011, CONSTRUCTION PRODUCT REGULATION

and the following directives

2014/53/EU (RED)

2011/65/EU 2015/863/EU, 2017/2102/EU, (RoHS)

2009/125/EC (Ecodesign)

And the following harmonised standards and/or technical specifications have been applied:

EN 16510-1; EN 16510-2-6; EN 55014-1; EN 55014-2; EN 61000-3-2; EN 61000-3-3; EN 60335-1; EN 60335-2-102; EN 62233;

EN 50581; ETSI EN 300220-1

All local regulations, including those referring to national and European standards, must be respected when installing the appliance.

Remote control: Synthetic Declaration of Conformity (DoC)

The manufacturer Aico S.r.I. declares that the Remote Control, with the Ravelli brand and model PNET00003 (Palm Touch) is in conformity with the relevant Union harmonisation legislation: 2014/53/EU (RED), and that the following harmonised standards and/ or technical specifications have been applied: ETSI EN 301 489-3, ETSI EN 301 489-1, EN 60950-1 A11+A1+A12+AC+A2, EN 62479.

These declarations can be found in full format on the website www.ravelligroup.it.

Pag.11

WARRANTY

Read the warranty conditions contained below.

Warranty conditions

The warranty for the Customer is acknowledged by the Dealer under the terms of law.

The Dealer acknowledges the warranty only if the product has not been tampered with and only if it has been installed in accordance with the Manufacturer's instructions.

The limited warranty covers manufacturing material defects, as long as the product has not broken sue to an incorrect use, negligence, incorrect connection, tampering, installation errors.

The warranty becomes null and void even if only one requirement in this manual is not complied with.

The following are not covered by warranty:

- the combustion chamber refractory stones;
- · the door glass;
- · the gaskets;
- the paint job;
- · the stainless steel or cast iron combustion grille;
- · the resistance;
- the Majolica cladding;
- the aesthetic parts;
- any damages caused by unsuitable installation and/or use of the product and/or shortcomings on the part of the customer.

The use of poor quality pellet or any other unauthorised fuel may damage the product's components, cause its warranty to be voided and as a result eliminate the connected manufacturer liability.

It is therefore recommended to use good quality pellet that fulfils the requirements listed in the dedicated chapter.

All damages caused by transportation are not recognised, for this reason it is recommended to carefully check goods upon receipt, immediately warning the reseller of any damage.

Registration of warranty



To activate the warranty, it is necessary to register the product on the Guarantee Portal on the website www.ravelligroup.it, by entering your data and the purchase receipt.

Info and problems

Dealers authorised by Ravelli use a trained Technical Service Centre network to meet the Customer's requirements. For any information or request for assistance, please contact your Dealer or the Technical Service Centre.



GENERAL INFORMATION

Supply and safe-keeping

The manual is supplied in printed format.

Keep this manual safe, with the appliance, so that the user can consult it easily.

The manual is an integral part, for safety reasons, therefore:

- it must be kept intact (in full). If it gets lost or ruined it is necessary to immediately ask for a new copy:
- it must be kept with the appliance until demolition (including relocation, sale, rental, lease, etc...).

The Manufacturer will not be held liable for improper use of the appliance and/or damage caused by operations that are not set forth in the technical documentation.

Language

The original manual was written in Italian.

Any translations into additional languages must be carried out based on the original instructions.


The Manufacturer is liable for the information contained in the original instructions; the translations into different languages cannot be fully verified therefore if any inconsistency arises it will be necessary to follow the text in the original language or contact our Technical Documentation Office.

Symbols used in the manual

symbol	definition
*	This symbol is used to identify particularly important information in the manual. This information also concerns the safety of users involved in using the appliance.
1	This symbol is used to identify important warnings for the safety of the user and/or the appliance.

SAFETY MEASURES

General safety warnings



- 1 Appliance installation, system verification, operation verification and initial calibration must be carried out exclusively by qualified and authorised staff.
- The appliance needs to be connected to a single chimney that guarantees the draught declared by the Manufacturer and observes the installation regulations that apply to the installation site.
- 1 The room where the appliance is installed must have an air intake.
- 1 The appliance must not be used as an incinerator or differently from its purpose

Pag.13



- Do not use any fuel other than fire pellet. It is strictly forbidden. to use liquid fuels.
- It is prohibited to use the appliance with the door or ash drawer open or the glass broken.
- Do not touch the hot surfaces of the appliance without suitable protective equipment, to avoid getting burned. When it is running, the outer surfaces reach hot temperatures to the touch.
- It is forbidden to make unauthorised changes to the appliance.
- Before using the appliance it is necessary to know the position. and function of the controls.
- If the chimney catches fire you must call the fire brigade.
- original spare parts. Any tampering ! Only use and/or replacements that have not been authorised by Ravelli can pose a danger to the user's safety.
- In the event of particularly adverse weather conditions, the safety systems could intervene and switch off the appliance. In any case, doe not disable the safety systems.

Residual risks

The appliance was designed so as to guarantee the user's essential safety requirements.

Safety was integrated into the appliance's design and construction

as múch as possible.

For every residual risk there is a description of the risk and the zone or part that is applies to (unless the risk applies to the entire appliance overall). Procedure-related information is also provided on how to avoid the risk and on the correct use of the personal protective equipment required by and made compulsory by the Manufacturer.



Residual	Description procedure-related information	
risk		
Risk of burns	When the appliance is running, it may reach high temperatures to the touch, especially on its external surfaces. Take care to avoid burns and use the specific tools if necessary. Use the glove if present to open the pellet cover for loading operations.	

DESCRIPTION OF THE APPLIANCE Intended use

The appliance in question is intended for:

Operation	Allowed fuel	Forbidden	Setting
Domestic space heating by burning:		Any fuel other than the permitted ones.	Residential or Commercial

The appliance is designed and built to work safely if:

- it is installed by qualified staff according to the specific standards; it is used within the limits declared in the contract and herein;
- the operating manual procedures are followed;
- routine maintenance is carried out according to the times and methods set forth:
- extraordinary maintenance is promptly carried out when needed;
- safety devices are not removed and/or bypassed.

This appliance must be intended for the use it was specifically designed for.

Reasonably foreseeable incorrect use

Reasonably foreseeable incorrect use is listed below:

- using the appliance as an incinerator;
- using the appliance with fuel other than pellet;
- using the appliance with liquid fuels;
- using the appliance with the door open and the ash drawer out. Any use of the appliance other than intended must be preventively authorised in writing by the Manufacturer. Without said written authorisation, the use is considered "improper". Any contractual and non-contractual liability of the manufacturer is excluded for damages to persons, animals or property due to installation and maintenance adjustment errors and improper use.



Obligations and forbidden actions

Obligations

The user must:

read this instructions manual before performing any operation

on the appliance;

the appliance must not be used by children under the age of 8 or by people with reduced physical, sensorial or mental capacities or without experience or without the necessary knowledge, and always with supervision;

do not use the appliance improperly, i.e. for uses other than those described in the "INTENDED USE" paragraph;

it is strictly forbidden to use liquid fuels;

- keep objects that are not heat and/or flame-resistant at a safe distance:
- only and exclusively load the appliance with pellet with the cháracteristics described herein;

connect the appliance to a regulation chimney;

provide a suitable system for the supply of combustion air (air intake or intake duct for watertight appliances);

always perform maintenance with the appliance off and cold;

perform cleaning activities at the frequency stated herein;

use original parts recommended by the Manufacturer.

Forbidden actions

The user must never:

remove or change the safety devices without authorisation;

- perform operations or manoeuvres of his/her own initiative that are not part of his/her job description, meaning that he/she might jeopardise his/her own safety and that of others;
- use fuels other than pellet and those allowed for lighting;

use the appliance as an incinerator;

use flammable or explosive substances near the appliance during operation;

use the appliance with the door open and/or with the glass ruined

or broken:

close the combustion air and smoke outlet openings, whatsoever;

use the appliance to dry laundry;

replace or change some of the appliance parts.



Rev.0 09/07/2025

Use and maintenance manual Circular



Pag.16

Characteristics of the fuel

Wood pellet is a fuel made of pressed wood sawdust, often recovered from processing scraps of carpentries. The material used cannot contain any extraneous substance such as, for example, glue, lacquer or synthetic substances.

The sawdust, once it has been dried and cleaned from impurities, is pressed using a die with holes: as a result of high pressure, the sawdust heats up by activating the natural wood binders; this way the pellet maintains its shape even without adding artificial substances.

Wood pellet density varies based on the type of wood and can exceed that of natural wood by 1.5 - 2 times.

The cylinders have a diameter of 6 mm and a variable length between 10 and 40 mm.

Their density is equal to approximately 650 kg/m³. Due to their low water content (< 10%) they have a high energy content.

The UNI EN ISO 17225-2:2014 standard (that replaces the EN PLUS standard) defines pellet quality by specifying three classes: A1, A2 and B. Maintain fuels and other flammables at a suitable distance.

Ravelli recommends using wood pellet classified A1 and A2 according to the EN ISO 17225-2:2014 standard, or certified DIN PLUS (more restrictive than the A1 class) or ONORM M 7135. Pellet may be light or dark coloured, it is normally bagged into bags that show the name of the producer, the main characteristics and classification according to standards.



Only use certified pellets. Poor-quality pellets can increase the rate at which dirt builds up on the glass and increase maintenance work.




Using fuel that is not compliant with the above will void the warranty.



TECHNICAL CHARACTERISTICS

Technical diagram Circular 7 - Circular 9 CX


	Unit of measurement	Circular 7 CX - Circular 9 CX
Height	mm	1208
Width	mm	520
Depth	mm	540
Weight	kg	150






Main parts

Α	Ventilation grid
В	Pellet hopper lid
С	Door
D	Combustion chamber
Е	Fire pot
F	Ash chute
G	Ash drawer
Н	Control panel



Minimum distance from flammable materials



d _R	Rear	200 mm
d _s	Front / Sides	200 mm
d _c	Ceiling	750 mm
d _p	Front	1500 mm
d _F	Front to floor	800 mm
d _L	Lateral Radial	800 mm
d _B	Floor	30 mm
d _{non}	Minimum distances from not flammable walls	50 mm

EN

Description of operation

Ravelli Circular pellet stoves are home heating appliances powered by wood pellets with automatic loading. They are suitable for use as a secondary heating system or as a support for the main heating system.

The heat generated by pellet combustion is diffused in the installation room by radiation and natural convection. It is possible to choose whether to activate the front fan or keep the stove in operation by natural convection.

The stove is controlled by an electronic control unit that manages the start-up, operation and shutdown phases and also includes many other functions for control, programming and safety.

The user can choose the operating power from 5 levels, or set the temperature to be maintained in the room. In this case the stove will manage the power to ensure maximum comfort. Among the functions of the electronic control unit there is also that of being able to program the start-up and shutdown of the stove, setting the weekly chronothermostat.

All this can be done comfortably from the sofa using the handheld remote control.

Ravelli's patented cleaning system minimises maintenance by the user. There is no longer any need to clean the brazier before each lighting and all cleaning operations are reduced to a minimum.

This stove has been designed for hermetic installations, so it can be installed in the traditional way, or by taking air directly from outside.

Automatic cleaning system

The stove is equipped with atuomatic brazier cleaning system. This means that there is no need to carry out daily manual cleaning of the brazier or every time the stove is lit. The automatic cleaning system is activated every time the stove is lit and after 6 hours of continuous operation. The cleaning cycle, which involves shutting down, automatic cleaning and restarting the stove, takes about 10 minutes. During this period the heating is guaranteed by the heat accumulated by the appliance itself. Note: the times indicated are those set by default by the Manufacturer.



Rev.0 09/07/2025

Use and maintenance manual Circular



Pag.20

Recharge the fuel



Use only wood pellets, the characteristics shown in this manual.



During pellet loading prevent the pellet bag from coming into contact with hot surfaces.



It is not recommended to empty the pellet bag directly into the hopper to avoid depositing wood sawdust on the bottom of the hopper.

To load the pellets inside the hopper, proceed as described below:

Step	Action
1	Lift the panel and open the pellet hopper cover
2	Pour the pellets into the hopper
3	Close the pellet hopper cover

Doors opening

The combustion chamber door, the pellet hopper lid and the ash drawer can only be opened when the stove is in the OFF state. If one of them is not closed, the pellet supply is interrupted, the control unit emits an acoustic warning signal, while the symbol appears on the display:



In this condition, by touching the CONFIRM button you can read the detail of the warning: "doors and ash pan open". If the combustion chamber door, the pellet hopper lid and / or the ash drawer are not closed within 1 minute, the stove switches off signaling ALARM 07. Opening the doors also interrupts the automatic cleaning phase of the brazier. In the event of a prolonged interruption of the cleaning phase, ALARM 19 may appear.

Remember that in the presence of an alarm the stove will have to be restarted manually.

User training

Once installation is complete, the user must always be fully trained in the functions and characteristics of the stove by the technician authorized by Ravelli to ensure optimal and safe use.

The training should cover the following topics:

- · Description of the stove, its operation and basic settings
- · How to turn the stove on and off safely
- · Fuel storage and refilling
- What to do in the event of an alarm, in particular that of "no ignition"
- · How to clean the stove correctly and the importance of performing it on a regular basis
- · It is advisable to schedule the first annual maintenance

EN



Safety devices

The stove has been designed and equipped with safety systems to minimize user risks.

It is equipped with the safety devices listed in the following table, which also intervene in case of failure of the electronic board.

Use and maintenance manual Circular

Element	Description
Pellet tank thermostat	If the temperature exceeds the set safety value, it immediately stops the pellet loading motor and the stove is automatically switched off; to restart it, it is necessary to wait until it has cooled down.
Pressure switch	If the pressure in the smoke outlet duct is too high (a sign that the smoke evacuation system is obstructed) it immediately stops the pellet loading motor and the stove switches off automatically.
Pressure switch for closing combustion chamber door, ash drawer and pellet hopper lid	If the door of the combustion chamber, the ash drawer or the pellet hopper lid are not properly closed, it immediately stops the pellet loading motor; if they are not closed within 60 seconds, the stove switches off automatically.
Electrical safety	In case of failure of the electrical components or wiring, the fuse and grounding keep the appliance safe. It is necessary that the electrical system of the house is up to standard, equipped with a grounding circuit and all the safety systems required by the standards.

It should be noted that the stove's operating program has been designed to stop stove operation in the event of malfunctions:

Anomalies	Description
Temperature in the combustion chamber	If the temperature probe in the combustion chamber detects temperatures that are too high or too low, the stove is switched off and the relative alarm is displayed.
Flue gas temperature	If the temperature probe at the smoke outlet detects temperatures that are too high, the stove is switched off and the relative alarm is displayed.
Smoke fan break	If the fan stops, the electronic board blocks the supply of pellets and the alarm is displayed.
Gear motor failure	If the gear motor stops, the appliance switches off safely.
Temporary power failure	If a power failure occurs during operation, when the power returns the temperature in the combustion chamber is checked and, if necessary, the stove goes into cooling mode.
No ignition	If no flame develops during the ignition phase, the stove goes into alarm.



It is forbidden to tamper with the safety devices. Restarting the product is only possible after eliminating the cause that caused the intervention of the safety system. To understand which anomaly occurs, consult this manual which explains, depending on the alarm message that the device displays, how to intervene on it.



If the problem persists, contact the Support Service.



SHIPPING AND INSTALLATION

Safety warnings for transportation and installation



The appliance must be installed by a qualified technician, who must issue a declaration of conformity of the system to the purchaser, taking full responsibility for appliance installation and correct operation.



The appliance installation site must be chosen so that the generated heat can spread evenly throughout the rooms that you wish to heat.



During transport and storage, avoid exposure to rain or persistent humidity.



The appliance needs to be connected to a single chimney that guarantees the draught declared by the Manufacturer and observes the installation regulations that apply to the installation site.



The room where the appliance is installed must have an air intake.



The air vent must be installed in such a way that it can not be blocked.

The Manufacturer will not be held liable for installation that is not compliant with the laws in force, incorrect air circulation in the rooms and inappropriate use of the appliance.

In particular, it is necessary:

- that the appliance be connected to a smoke evacuation system duly sized to guarantee the draught declared by the Manufacturer, that is tight and observes the distances from flammable materials;
- that there is a suitable combustion air intake in compliance with the type of installed product;
- that other installed combustion appliances or devices do not create a vacuum in the room where the appliance is installed;
- that the safety distances from flammable materials are observed.

Verification of system compatibility has a priority over any other assembly or installation operation.



Local administrative regulations and particular requirements of the authorities pertaining to the installation of combustion appliances, the air intake and the smoke evacuation system, may vary based on region or nation. Check with your local authorities if there are stricter laws than set forth herein.

Packaging

When the appliance arrives, check:

- · that it is the model you ordered;
- that it has not been damaged during shipping.

Any complaints must be reported to the deliveryman (also on the delivery note) upon receival.



Check the capacity of the floor before handling and positioning the appliance.

To handle the appliance in its packaging, follow the procedure below:

- 1 Position the pallet truck forks in the slots under the wooden pallet.
- 2 Lift slowly.
- 3 Place the appliance near the chosen location for installation.



The appliance always needs to be handled vertically. Take extra care to protect the door and its glass against mechanical impact that could jeopardise their integrity

To unpack the appliance, follow the procedure described below:

- 1 Cut the straps and remove the wooden reinforcement frame resting on the box
- 2 Slowly lift the cardboard box
- 3 Remove any bubble-wrap or similar
- 4 Remove the appliance from the pallet and position the appliance in the chosen location, ensuring that it is compliant with the directions.

If the appliance is packed in a wooden cage, replace steps 1 and 2 of the previous table with the steps described below:

- 1 Remove the side straps by unscrewing the fixing screws
- 2 Remove the upper and side wooden cage

Pag.23



Use suitable equipment to remove the boards or wooden parts of packing.



The end user is responsible for disposing of the packaging in accordance with the laws in force in the country of installation.

Set-ups for the smoke evacuation system



Be careful when building the smoke evacuation system and observe the regulations in force in the country where the appliance is installed.



The Manufacturer will not be held liable for incorrectly sized and non-regulation smoke evacuation systems.

Smoke ducts and fittings

The term smoke duct indicates all ducts that connect the combustion equipment to the chimney.

The following requirements need to be applied:

- observe product standard EN 1856-2;
- the horizontal sections must have a minimum slope of 3% upwards;
- the length of the horizontal section must be as minimum as possible, and its projection on the horizontal plane must not exceed 2 metres;
- changes in direction must not have an angle of more than 90° (45° bends are recommended);
- the number of direction changes, including the one necessary for insertion into the chimney, must not exceed 3;
- the cross section must have a constant diameter, the same from where it exits the firebox up to the fitting into the chimney;
- it is forbidden to use flexible metal and fibre cement pipes;
- the smoke ducts must not pass through rooms where the installation of combustion appliances is prohibited, rooms at risk of
 fire, fire compartmental rooms, rooms where there is a specific risk of fire, or spaces that cannot be inspected
- In any case, the smoke ducts must be sealed against combustion products and condensation, as well as insulated if they lead
 outside of the installation room.
- Installing manual draught adjustment devices is not allowed
- Provide the sampling point for measuring the draught and smoke analysis as per UNI10683 and UNI10389-2 standards

Chimnev

The chimney is a particularly important element for correct appliance operation.



The chimney must be sized so as to guarantee the draught declared by the Manufacturer.



Do not connect the appliance to a collective chimney.

The chimney must be built applying the following regulations:

- it must observe product standard EN 1856-1;
- it must be made of materials that are suitable to guarantee resistance against normal mechanical, chemical and thermal stress and be correctly thermally insulated to limit the formation of condensation;
- it must be mainly vertical and not feature any bottlenecks along its entire length;
- it must be correctly spaced with an air gap and insulated from flammable materials;
- there must be a maximum of 2 changes in direction and angles must not exceed 45°;
- the chimney inside the home, however, must be insulated and can be inserted into a skylight shaft, as long as it respects standards regarding placing inside a tube;
- the smoke conduit must be connected to the chimney using a "T" fitting with an inspection collection chamber for combustion residue and especially for collecting condensation.



It is necessary to check the safety distances that need to be observed when there are flammable materials and the type of insulating material that needs to be used is on the chimney data plate.



Use watertight pipes with silicone seals.



It is forbidden to use the discharge mounted directly on the wall or directed towards indoor spaces and any other type of discharge that is not set forth by the regulation in force in the country of installation (Note: in Italy only roof-discharge is allowed).

Chimney pot

The chimney pot, i.e. the top end of the chimney, must fulfil the following characteristics:

- the cross-section of the smoke outlet must be at least twice the internal cross-section of the chimney;
- it must stop water or snow from getting in;
- make sure the smoke is taken away even when there is wind (wind resistant chimney pot);
- the outlet height must be outside of the reflux zone (refer to national and local regulations to calculate the reflux zone);
- it must always be built at a distance from antennas or dishes, it must never be used as support.



Rev.0 09/07/2025

Use and maintenance manual Circular

Pag.24



Installation



For appliance installation and use it is necessary to observe all of the local, national and European laws and regulations.



Appliance installation and the preparation of the building work must observe the regulation in force in the country of installation (ITALY = UNI 10683).



The installation activities must be carried out by a technician that is qualified and/or authorised by the Manufacturer. The staff in charge of installation must issue a declaration of conformity of the system to the buyer, whereby they take full responsibility for the final installation and good operation of the installed product.



Ravelli shall not be held liable if these precautions are not followed.

Requirements for the installation premises

The appliance installation room must be sufficiently ventilated. To fulfil this requisite it is necessary to equip the room with an air intake connected to the outdoors.



The installation room must have an air intake with a free cross-section of at least 80 cm² or 100 cm² in case of boiler.



For installation in the presence of other combustion appliances or VMC system it is necessary to check the appliance for correct operation.

The appliance must be placed inside living quarters. It must never be installed outdoors. The volume of the room where it is installed must be suitable for the power of the appliance and, in any case, greater than 15 m³.



When extraction fans (example: extraction hoods) are used in the same room or space as the appliance, this can cause problems to appliance operation.



The appliance must be installed on a floor with suitable load capacity. If the existing position does not fulfil this requirement, it is necessary to take due measures (for example, using a load distribution plate).



Provide due insulation if the surface is made of flammable material.


If the side walls adjacent to the appliance are made of a flammable material, it will be necessary to position the appliance at least 30 cm from them.

If the floor that the appliance is standing on is flammable, we recommend duly insulating it. Objects and parts that are heat-sensitive or flammable cannot be stored near the appliance; in any case, keep such objects outside the area bounded by the minimum distances indicated above.

Appliance installation must guarantee easy access to clean the appliance, the exhaust ducts and the chimney.


EN

Installation example




This type of installation (See Fig.1) requires an insulated chimney pot, even if the entire conduit is installed inside the building. Besides, the structure must be inserted into a properly ventilated skylight shaft.

In the lower part of the chimney pot there is an inspection cover, properly isolated from wind and rain.





It is prohibited to install a 90° bend for the initial segment, since the ashes would quickly obstruct smoke passage, causing draught problems in the appliance. (See Fig. 2)




It is possible to use an existing chimney or a shaft via ducting. For this type of installation the standards on ducted smoke evacuation systems must be complied with. In the lower part of the chimney pot, inside the home, there is a "T" type fitting installed; externally there is another one installed, so that the outside section can be inspected.

It is prohibited to install two 90° bend, since the ashes would quickly obstruct smoke passage, causing draught problems in the appliance. (See Fig. 2)







This type of installation (See Fig.4) requires an insulated chimney pot, even if the entire smoke conduit is installed outside the building.

In the lower part of the chimney there is a "T" type fitting installed with inspection cap.

It is prohibited to install a 90° bend for the initial segment, since the ashes would quickly obstruct smoke passage, causing draught problems in the appliance. (See Fig.2)

This type of installation (See Fig.5) requires an insulated chimney pot, since the entire smoke conduit is installed inside the building, and the part is located inside a pre-existing chimney pot.

In the lower part of the appliance there is a "T" type fitting installed.

In the lower part of the appliance there is a "T" type fitting installed with inspection cap just like for the chimney pot.

It is prohibited to install a 90° bend for the initial segment, since the ashes would quickly obstruct smoke passage, causing draught problems in the appliance. (See Fig.2)

This type of installation (See Fig.6) requires a horizontal section to connect to a pre-existing chimney pot.

Respect the slope indicated in figure, in order to reduce the ashes depositing in the horizontal tube. In the lower part of the chimney pot, there is a "T" type fitting installed with inspection cap, in the same was as the chimney pot opening.

It is prohibited to install a 90° bend for the initial segment, since the ashes would quickly obstruct smoke passage, causing draught problems in the appliance. (See Fig.2)

Not supplied

with the stove



CONNECTATIONS



Connections must be carried out by a qualified technician and/or authorised by the manufacturer.



From the installer's point of view, the type of cable, with its cross-section, to be fitted in case of replacement is: H05RR-F sect.3G0.75

Flue connection



The chimney must be sized to ensure the draught declared by the manufacturer.




The stove must be connected to a single flue. It is forbidden to connect the stove to a flue shared with other combustion appliances or hood flues.




The chimney must be inspectable for cleaning.

Concentric installation

The stove is designed for airtight installation.
Follow the regulations in force in your region for installation.
Connect the 80/130 concentric duct for air supply and flue gas discharge.




Upper flue gas outlet Ø80 with internal air intake











Rev.0 09/07/2025 Use and maintenance manual Circular





Pag.28












EN


Rev.0 09/07/2025 Pag.30

Use and maintenance manual Circular











Steps 9 and 10 are only necessary to connect combustion air directly from outside via a pipe.

Electrical connection

The plug of the stove's power cable must only be connected after the installation and assembly of the stove has been completed, and must remain accessible after installation.

To carry out the electrical connection, proceed as described below:

Connect the power cable first to the plug on the back of the stove and then to a wall socket.

Power the stove by turning the switch to position (I)



When the stove is not in use, it is advisable to disconnect the power cable.



Take care that the power cable (and any other cables outside the appliance) do not come into contact with hot surfaces.



Ensure that the electrical installation is earthed




For direct connection to the grid, a device must be provided to ensure disconnection from the grid, with a contact opening distance that allows complete disconnection under the conditions of overvoltage category III, in accordance with the installation rules.



It is recommended that authorised personnel pay particular attention to electrical connections after any work on the product.



If the power cable is damaged, it must be replaced by the manufacturer or its technical service department or a similarly qualified person, so as to prevent any risk





Connection of external probe or thermostat

To manage the stove using an external thermostat (optional), connect it to the appropriate terminals on the board, as shown in the Electric scheme.



Connect an open/closed external thermostat, therefore potential-free



If you wish to detect the ambient temperature by means of an external thermostat (optional), this must be connected to the appropriate connector on the rear side of the stove; and you will have to activate the reading in "SETTINGS - ENABLE THERMOSTAT." On display appears the writing TON / TOFF based on thermostat request.




Connect an external thermostat with a simple dry contact, therefore, not powered, moreover, we recommend you use a thermostat with a minimum offset of 3°C if you intend to use the "comfort clima" function.

Testing and commissioning

Stove start-up must be preceded by testing, which includes an operational check of the following elements:

- connection to the smoke evacuation system;
- electrical connections;
- operation of any connected external probes;
- checking that all materials used to build the smoke duct, chimney and chimney pot are regulation and suitable for use.

The testing is positive only when all operational phases have been completed without any anomaly being detected.




EN



CONTROLS AND USE

Control panel description



Button 1: Switch on/off

POWER SETTING

You can use button 2 to adjust the power. To increase the power, press button 2 again.

- Only LED 3 lit = power 1
- LED 3 lit and LED 4 flashing = power 2
- LED 3 and 4 both flashing = power 3
- LED 3 flashing and LED 4 lit = power 4
- LED 3 and 4 both lit = power 5

LED 6 (red): Error

7: Remote control cable connection socket

The yellow flashing LEDs (3,4) indicate that the circuit board is waiting to receive the signal from the remote control.

Radio touch remote control initialization

The remote control, after a first short screen showing the Ravelli logo, will list the languages available in the menu. Select the desired language with the scroll buttons and confirm your selection with the confirmation button.

> ITALIANO **ENGLISH** FRANCAIS NEDERLANDS ESPANIOL

In order to operate correctly, the remote control should be interfaced with the electronic board installed inside the stove. For this reason, on display appears the following message:



If the remote control is used for the first time, select YES using the selection keys and confirm with the dedicated key. On the display of the remote control appears the following:

> PRESS THE TWO KEYS ON THE **EMERGENCY**

Press and hold the emergency console buttons (1,2) for a few seconds to initialize the remote control.

By pressing the dial key on the remote control, the components communicate with each other. A check mark on the display, accompanied by an acoustic signal, indicates that the remote control initialization operation has been successfully completed.






In case of battery replacement, it is not necessary to perform the initialization procedure of the remote control. In this case, when the display will show the message "FIRST INSTALLATION?", select NO and press the dial key.



Description of the radio touch remote control

The remote control looks like the following picture:

The information below will familiarize you with the product and give you the best performance.



- 1 Increase button "UP" (selection key)
- 2 Decrease key "DOWN" (selection key)
- 3 ON/OFF or reset from "Sleep" mode key.
- 4 Display
- 5 Key for accessing the MENU and back
- 6 Confirmation key



In "Sleep" mode, the remote control screen is darkened, but radio communication with the stove is still active in order to reduce battery consumption.

How to insert the batteries in the remote control:

Remove the protective cover of the battery on the back of the remote control as shown in Figure A, and insert the 3 batteries (mini pen style battery AAA 1.5V) in the housing of the remote control and observe the poles. Install the battery protective cover as shown in figure B






What happens if the batteries are empty

If the battery is discharged, within the "drop" is shown a symbol that indicates that the battery is empty, while maintaining active the features of your device.



As soon as the level of the battery prevents the radio communication the remote control displays on full screen the picture of empty battery and all device functions are locked until the batteries are replaced.






If not in use for a long time, we recommend removing the batteries from the remote control.

Description of the display

The display of the remote control is described below (in "Home" mode):



EN



After 5 minutes of inactivity, the remote control display dims to "SLEEP" mode while maintaining the radio connection to the stove. A subsequent press of the ON/OFF key reactivates the display.




The first press of any key with active display turns on its backlight, not interpreting it as a command

The display is subdivided into three parts:

1- It shows the current room temperature measured by the remote control. Moreover, if you press the DOWN scroll key you will display the temperature settings that can be changed using the two UP/DOWN keys. Any change made is confirmed automatically within 3 seconds from the change or by pressing the confirmation key. A sound signal indicates that the change has been confirme.



- 2- Icon indicating the status of the stove (see synthetic phase diagrams).
- 3- In the inactive phases (combined with the second part of the display) indicates the state of the stove. In the active phases, it indicates the operating power of the stove. In addition, by pressing the DOWN scroll button, you can display the power settings, that can be edited using the two scroll keys UP/DOWN: The confirmation of any change takes place automatically within 3 seconds from the change or by pressing the confirmation key. A sound signal indicates that the change has been confirmed.



Time and date setting


Below are given the steps for accessing the relative menu




access

MENU page


MENU USER TECHNICIAN **PRODUCER**



Press the key "confirm" to access the USER page







Press the key "selection" for 'selection' to switch to the second page of USER MENU and select SETTINGS.



SETTING DATE - HOUR **ENABLE T.EXT** CONTRAST **VERSION FW** ADJUST LANGUAGE

hh Day mm 00 :00 -MA mm aa 99 00 / 00 00

Press the key "confirm" to access the page DATE-TIME

Press the key
"confirm" to
access the
SETTINGS
nage





Press the increase key to change every single value



Press the increase key to change every single value



Press "confirm" to confirm the settings and switch to the next



By pressing the key "back" for several times you will display the stand-by page.



PROCEDURES FOR USE



If the chimney catches fire you must call the fire brigade immediately.

Checks prior to start-up



You have read and perfectly understood the contents of this instructions manual.

Before lighting the stove, you must ensure that:

- · the pellet tank is full;
- · the combustion chamber is clean;
- the fire door and ash drawer seals are functioning properly;
- · the electrical plug is connected correctly;
- all items that could burn (instructions, various adhesive labels) have been removed;
- the brazier, if removable, is correctly positioned in its housing.



During the first hours of use the paints used for the stove finish may release an unpleasant odour. You might also smell the typical odour of metal parts subject to high temperatures. Make sure sufficient air circulation is guaranteed in the room. These unavoidable inconveniences will disappear after the first hours of operation. To reduce your discomfort to a minimum, keep the stove on for a few hours on low power and in the beginning, do not overload it, avoiding intense heating-cooling cycles



At the initial start-up, the paint finishes drying and hardens. Accordingly, to avoid ruining it, we advise you not to touch the stove's painted surfaces at this time.

Auger loading

Before starting the stove for the first time, whenever the stove is in alarm "06 - Pellets finished", and in any case whenever the hopper has emptied completely, the initial feed screw loading is required. This phase serves to fill the pellet loading system so that, at the time of ignition, the correct pellet loading takes place in the brazier. In the event that the feed screw operations are not carried out, there may be stove ignition failures.



After loading the auger and before lighting the stove, always remember to empty the brazier and check that the brazier is clean. Never empty the brazier inside the hopper.




After each maintenance operation, make sure that the brazier is positioned correctly in its seat.



In models with self-cleaning brazier it is not necessary to remove the pellets in the brazier: the pellets loaded are sufficient for subsequent ignition.








LOADING AUGER
CHRONOTHERMOSTAT
SET AIR-PELLET
STOVE STATUS

USER





Press the "menu access" button to access the MENU screen.

Press the "confirm" button to access the USER screen

Press the "confirm" button to activate feed screw rotation

Switching the appliance on and off

From the "Home" screen, it is possible to switch the stove on and off by keeping the ON / OFF button pressed on the device for a few seconds. An acoustic signal will warn you that the appliance has switched on or off. In case it is not possible using your remote control you can switch the appliance on / off using the appropriate button on the electronic board.



Do not switch off the heater by unplugging the plug from the wall socket.



The appearance of the "SET RDS" message indicates that the initial parameter testing and calibration procedure was not carried out correctly. This indication does not imply blocking the stove (see SIGNALING POP UP section).

Pag.37

Failed ignition

If the system does not detect the ignition of the flame within the preset time, operation will be blocked with the "No ignition" alarm. Before relighting the stove, check that there are pellets in the hopper, that the door and ash drawer compartment are closed, that there are no obstructions to the combustion air inlet system and above all that, in models without self-cleaning brazier, the brazier is empty, clean and correctly positioned. If the problem persists, it could be due to a technical problem (ignition plug, adjustments, etc ...), so please contact a Ravelli CAT.



The accumulation of unburned pellets in the brazier after a failed ignition must be removed before proceeding with a new ignition.



The brazier could be very hot: danger of burns!



Never empty the brazier inside the hopper.

Setting operating temperature and power:


Set the two values following the indications given in the chapter "Description of the display"

OPERATING PHASES OF THE APPLIANCE


Sequence of ignition phases

IGNITION - initial pellet loading phase;

FLAME LIGHT - flame stabilization phase and reduction of combustible inside the brazier;




WORK - operation phase described in the dedicated chapter;



Modulation

During the work phase, the appliance should reach the room temperature set; when this condition is met, the stove switches to MODULATION mode in which fuel consumption is minimum.





If you wish to detect the ambient temperature by means of an external thermostat (optional), this must be connected to the appropriate connector on the rear side of the stove; and you will have to activate the reading in "SETTINGS - ENABLE THERMOSTAT." On display appears the writing TON / TOFF based on thermostat request.



Connect an external thermostat with a simple dry contact, therefore, not powered, moreover, we recommend you use a thermostat with a minimum offset of 3°C if you ntend to use the comfort clima function.

Description of menu functions



Press the key to access the MENU page

MENU
USER
TECHNICIAN PRODUCER




The TECHNICIAN and PRODUCER menus are password protected. Changing parameters within these menus could compromise the operation and safety of the stove. In this case the warranty will be invalidated.



Chronothermostat

With the Chrono-thermostat function you can program the automatic switch ON/OFF of the stove for each day of the week for each day of the week in 4 independent time intervals (SET CHRONO 1-2-3-4). Below are given the steps for accessing the relative menu starting from "Home" mode.



The exit key shows the CHRONO menu to set other variables related to the menu functions.



To exit the page and return to "Home" page, press the button repeatedly.


Set air - pellet

The setting of the PELLET-FLOW mixture allows to adjust the combustion by varying the quantity of pellets loaded in the brazier and/or the quantity of air. In fact, by its nature, pellets vary in grain size and composition: even bags of pellets of the same brand can have different characteristics.

If combustion is not optimal, vary the flow parameter to adjust the combustion air. If air regulation alone is not sufficient, it may also be necessary to modify the pellet parameter.



Combustion regulation is an operation that requires a lot of experience. We recommend that you contact an Authorised Service Centre to calibrate the stove appropriately.





To exit the screen and return to the home screen, press the key repeatedly.

Stove status


RAVELLI


Below are given the steps for accessing the relative menu starting from "Home" mode.

"confirm"

to access the


USER page








Press the key several times to quickly switch to Stove STATUS.





In this mode you can check the proper operation of the most important parameters of the appliance. Here is a list of real data of the stove useful for service during inspection.

- RDS current reading RDS (m/s)
- RPM current smoke extractor speed (rpm)
- T fumes temperture (°C)
- Indication of stove status
- SET set value RDS (m/s)
- Df cold probe temperture RDS (°C)
- Sk: electronic board temperature (°C



To exit the STOVE STATUS screen and return to the Home screen, press the key repeatedly.

Comfort clima

The activation of this function enables the stove to reduce pellet consumption by activating the modulation phases, after the desired temperature has been reached. Subsequently, the stove checks that the temperature is maintained steady for a preset time (DELAY SWITCH OFF). If this condition is met, it automatically switches off, and on display appears the writing ECO. The stove turns on again when the temperature drops below the set threshold (DELTA RESTART).

USER


Below are given the steps for accessing the relative menu.



Press the key 'access menu" to

access

MENU page





USER page


SET AIR-PELLET STOVE STATUS Press the key "confirm" to access the



USER COMFORT CLIMA SETTING

Press the key "selection" for "selection" to switch to the second page of USER MENU and select CLIMATE COMFORT.

Once you have accessed the Comfort Clima menu, it is possible to operate on the 3 types of settings dedicated to the function:








COMFORT CLIMA ACTIVATE COMFORT DELTA RESTART DELAY SWITCH OFF












The first setting allows the activation of the COMFORT CLIMA function. This function is intended to ensure that the room tem perature set is maintained steady upon setting the maximum period of "X" minutes (SWITCH-OFF DELAY: 5 MIN) before switch-ing to ECO STOP phase. The STOVE maintains this state until the temperature drops below the set value (DELTA COMFORT CLIMA: 5°C). For example, with the room temperature at 21 °C, the stove switches of f when this temperature is reached and restarts when the temperature reaches 16°C (21°C - 5°C). You can also activate the function using an external thermostat, keeping in mind that this does not include the value of hysteresis.

Setting

Below are the steps to follow, starting from the Home screen, to access the Home menu.










Press the key "confirm" to access the USER page

LOADING AUGER CHRONOTHERMOSTAT SET AIR-PELLET STOVE STATUS





Press the key "selection" for "selection" to switch to the second page of USER MENU and select SETTINGS.

After following the above procedure

Settings > Enable thermostat



DATE - HOUR

ENABLE T.EXT

CONTRAST

VERSION FW

ADJUST

LANGUAGE

ENABLE THERMOSTAT

SETTING

Press the "enter" key to access the SETTINGS




Press the key
"selection" to switch to
ENABLE THERMOSTAT.

DATE - HOUR
ENABLE T.EXT
CONTRAST
VERSION FW
ADJUST
LANGUAGE

Press the key
"confirm"
to access the function









Press the key for several times to return to "STAND BY" page



In "Home" mode, instead of room temperature measured and settable, appears the line T ON if the room in which the thermostat is installed has not reached the temperature requested or the writing T OFF if the temperature in the room is reached.






Pag.41

Settings > Contrast

With this function you can change the contrast setting to improve the display of your remote control. The contrast setting to improve the display of the remote control display.




Press the key "confirm" to SETUP SETTINGS






Press the key 'selection" to switch to the function CONTRAST





Press the key "confirm to access the function





Use the UP/DOWN keys to change contrast setting and obtain a better visualisation of the information shown on the remote control set.

The value can vary from 0 to 100. 50 with respect to the standard value.




SETTING

By pressing the following key you will confirm of data and switch to the page within SETTINGS menu.

Settings > Firmware version










Press the key ection" to switch to CONTRAST



Press the key to access the function





By pressing the button you will confirm the data and switch to the page within the SETTINGS menu.


Settings > Adjust

The adjust function allows to modify the value read by the room probe inside the remote control, increasing or decreasing it by the set value (offset).

Make this adjustment carefully and only after having checked deviations from the actual room temperature with a reliable instrument!




Press the key "confirm" to access the SETUP






Press the key 'selection" to switch to the function VERSION FW.





Press the key "confirm" to access the function





UP" and "DOWN" buttons The value can vary from -10°C to 10°C. The standard value is 0°C.



Pressing the following key allows you to confirm the data and move to the screen within the SETTINGS menu.

Settings > Language

To access the next setting, follow the steps given above or simply remove and replace the batteries.

The device resets and prompts you again to select the language you want to set.



Rev.0 09/07/2025

Use and maintenance manual Circular



Pag.42


Ventilation menu (function present only for ducted and ventilated models)

The stoves with optional fan use the natural convection system which guarantees a considerable amount of heat in the room with the total absence of noise from the room ventilation. There is however the possibility, by accessing the menu below, to activate the optional ventilation according to the power you require.

Below are the steps to follow, starting from the Home screen, to access the relative menu.



Press the key "access menu" to access the MENU page






Press the key "confirm" to access the USER page USER
POWER SETTING
CHRONOTHERMOSTAT
SCREW LOADING
SET AIR-PELLET



Press the key "confirm" to quickly switch to VENTILATION.





Press the increase/decrease keys "increase/decrease" to change the ventilation.



To exit the page and return to Home page, press the button repeatedly.

<u>Control:</u> ventilation can be set from 0 to AUTO where 0 indicates that the same is disabled, setting from MIN to MAX enables selecting the heat distribution speed. If set to AUTO, the ventilation follows the power set on the stove.



If the AUTO function is not set, the fan is released from the stove's power, except when the flame passes in modulation, where the exchanger goes to minimum.



Stove phase general layout

	PHASE	DESCRIPTION
20°C 6 OFF	FINAL CLEANING	The stove is in the switch off phase and the cooling phase has not been completed yet.
20°C	IGNITION	The heater pre-heating phase has started and the pellets start to fall into the grate.
20°C	FLAME LIGHT	The pellets ignite and take advantage of the heat in the intake air that passes through the incandescent heater tube.
20°C	WORK	The stove has completed the switch on phase and runs at maximum set power
20°C modula	MODULATION	The room temperature set has been reached.
20°C ₹/11	FIRE POT CLEANING	Fire pot cleaning phase is active (periodic function).
20°C	ECO STOP	With Climate Comfort active, the stove switches to automatic switch-off mode when the room temperature set is reached (see the dedicated section).
20°C ፯ ON	WAITING START / RESTART	Switch-on is requested but with the stove in cooling phase; once this condition is met, it restarts automatically.
20°C 6 ON	IGNITION RESTART	The HOT restart phase is activated. Functioning is similar to the SWITCH ON phase
20°C	HOT SMOKES	The maximum fume temperature threshold has been reached. To facilitate cooling, the stove brings the capacity to a minimum with ventilation at power level 5, leading to a decrease in fume temperature.
20°C (1) OFF	OFF	The stove is off
20°C (10) ON	WAIT FOR PELLETS OUT OF	When the switch-on request from ECO-STOP mode coincides with an automatic switch-off condition (from the TIMER), the stove turns on ensuring total cleaning of the fire pot before switching to FINAL CLEANING.
20°C Carico Eccessivo	AUGER OVERFLOW	CONDITION: when the pellet setting (set pellets +5) is near the continuous load condition. SOLUTION: Set the value back to 0.
AL-05	ALARM (generic)	The stove is in alarm state; refer to the troubleshooting chapter.



Rev.0 09/07/2025

Use and maintenance manual Circular



P	a	9	4	4	

20°C i OFF	ANOMALY (general)	The stove has detected an anomaly; refer to the troubleshooting chapter. By pressing the confirmation key, the problem is described.
20°C ▼	AUTOMATIC CLEANING SYSTEM ACTIVE	For models with automatic cleaning system it indicates the operating state of the same.

Warning Pop -Up

	ANOMALY	DESCRIPTION
20°C × 111	SERVICE REQUEST	The threshold value of set work hours has been reached. The symbol displayed remains active throughout the work phase. Non-routine maintenance is required on the stove.

Alarms (table with reference codes)

	TITLE	REASON	SOLUTION
AL 01 BLACK OUT		No voltage during work phase	Press the switch off key and switch on the stove again
			If the problem persists, contact the Support Service
	SMOKE	The smoke probe is malfunctioning	Contact the Support Service
AL 02	PROBE FAILURE	The smoke probe is disconnected from the electronic board	Contact the Support Service
AL 03	OVERTEMP.	Combustion in the fire pot is not optimal due to clogging or obstructions of internal stove ducts inside the stove	Switch off the stove, clean the fire pot and the tube bundle and adjust the combustion setting the Pellet/Air values
	SMOKE		Contact the Support Service
			If the problem persists, contact the Support Service
		Fume exhaust encoder is not working or is connected incorrectly	Contact the Support Service
AL 04	FAN BROKEN	No power to fume extractor.	Contact the Support Service
		The fume extractor is blocked.	Contact the Support Service
	NO IGNITION	The pellet tank is empty.	Check for the presence of pellets in the container. Top up, if necessary.
AL 05		Pellet calibration and suction during switch on phase is incorrect.	Contact the Support Service
		The ignition coil is faulty or positioned incorrectly	Contact the Support Service
		The pellet tank is empty.	Check for the presence of pellets in the container. Top up, if necessary.
AL 06	NO PELLET	The gear motor is not loading pellets.	Empty the tank to see if there are any objects inside that may prevent proper operation of the auger.
		Not enough pellets loaded	Regulate pellets setting from "SET AIR/PELLETS"
			If the problem persists, contact the Support Service
	RESETTABLE THERMAL BREAKER	The manual reset thermostat connected to the hopper has been triggered	Reset the thermostat by pressing the button on the back of the stove
AL 07		Combustion in the fire pot is not optimal due to clogging or obstructions of internal stove ducts inside the stove	Switch off the stove, clean the fire pot and the tube bundle and adjust the combustion setting the Pellet/Air values
			Contact the Support Service





AUGER

ALARM

AL 25

Use and maintenance manual Circular

The flue is blocked. Check the flue is free and clean **AL 08 DEPRESSION** The vacuum meter is faulty. Check the mains voltage. **FUME** The fume exhaust system has a loss of **AL 12 EXHAUST** performance due to fan obstruction or voltage Check the mains voltage. **SYSTEM** drop. **AUGER AL 14** No cable connection to power the gear motor Check the mains voltage. **PHASE** An internal part of the electronic board that Check the flue is free and clean controls the pellet auger is faulty. **AUGER TRIAC AL 15** Possible voltage drops or incorrect input Check the mains voltage. voltage Reset the alarm and wait for the stove to switch to SHUTDOWN mode. Cut off and power again, the **CLEANER** The cleaner did not complete the movement system reactivates the cleaner searching the correct **AL 19 FAILURE** and is not in the correct position position again. If the problem persists, contact the Support Service

Contact the Support Service

Anomaly in auger geared motor operation.


EN



Wifi kit



Wifi external power supply kit (if applicable)






INSTALLATION QUICK GUIDE RAVELLI SMART WI-FI

Connect the WiFi module cable

Connect the WiFi module cable to the serial input of the product's eletronic board (examples A,B and C)



Carry out this operation only with the device cold and with the electrical plug unplugged. To install the WiFi module, the outer cladding of the device must be removed if present. For correct disassembly of the cladding, please see the cladding kit instructions. Reposition the cladding and reconnect the electrical plug when the operation has been completed.



App

Download the "Ravelli Smart Wi-fi" from...








the layout, some of the text or some graphic elements of the App may differ from the version shown in this guide.

Connection to the WiFi module

Open the App and click Scan QR Code, scan the WiFi module label and click Join.





In case your smartphone/tablet fails to recognize the QR code, you can pair manually.

From the smartphone/tablet, enter the menu

Android: Settings -> Connections -> Wi-Fi


iOS: Settings -> Wi-Fi

Select the network "WINET-XXXXXXXX" and enter the WPA key indicated on the label of your wi-fi device, taking care to enter upper or lower case characters as shown".



Connection to the WiFi network

Click in succession > Networks. The Select wifi network screen will appear. Click Scan for networks:select your WiFi network and enter the password if required. Close the App and go to point 5 to register your account.











Appliance eletronic board selection

Click on Model name e.g. KTR-AIR and then click Yes. The screen offers a list of firmware: once you have identified your model, click on Select > Yes. Close the App and go to step 6 to register the account.














Account registration

Deactivate the WiFi connection on your device, open the App and click Access to cloud. Select Register your account, enter the required information (the name must not contain spaces) and click Register.









Confirmation e-mail


A confirmation E-mail will arrive with the registration. Open the E-mail and click on the activation link. On your browser, the reserved area will open where you can register the WiFi device.

WiFi device registration

When you click the link in the confirmation E-mail, the window to register the new device will open: click Register your wifi device now!

STEP 1: enter the MAC addressand Reg Code(see module label);







Rev.0 09/07/2025


Use and maintenance manual Circular




Pag.50

STEP 2 enter the product serial number and give the module a name (e.g. living room stove);

STEP 3 complete with your information, click Next and then Complete registration.





Pag.51

MAINTENANCE

Safety warnings for maintenance



Maintenance of the stove must be performed at least once a year and should be planned in advance with the Technical Assistance Service.



In some conditions, such as turning the stove on and off or inappropriate use, the combustion products can contain small soot particles that build up in the smoke evacuation system. This can reduce the cross-section of the smoke duct and pose a fire risk. The smoke evacuation system must be inspected and cleaned at least once a year.



The maintenance operations must be carried out when the stove is cold and with the electrical power supply disconnected.

Before completing any maintenance operation, adopt the following precautions:

- Make sure that all stove parts are cold.
- Make sure that the ashes are completely cold.
- Always operate with equipment that is appropriate for maintenance.
- When maintenance is finished, re-install all of the dis-assembled parts before restarting operation.



The quality of the pellet, the stove operating mode and combustion control can affect maintenance activity frequency.

Cleaning



Perform the cleaning operations so as to guarantee correct stove operation.

The table below lists the necessary cleaning operations required for correct stove operation.


Parts / frequency	2-3 Days	30 Days	60/90 Days
Ash drawer		•	
Glass	•		
Combustion chamber		•	
Pellet tank		•	
Extraction duct			•




It is recommended in the early periods of use of the stove, or of a new type of pellet, to carry out cleaning operations frequently, so as to be able to assess the exact frequency of intervention.

Cleaning the ash drawer

The ash drawer must be cleaned every 30 days, (depending on the amount of time the stove is used and what type of pellet is used). To clean the ash drawer, proceed as follows.









Glass cleaning


With a cold stove, clean the glass with a cloth and glass cleaner.

Note: there are stove glass cleaning products available on the market.

Combustion chamber cleaning

To clean the ash drawer, proceed as follows:

Step	Action	
1	Vacuum the combustion chamber every day using a bin ash vacuum, making sure that the ashes are completely cold.	



Cleaning the pellet tank

To clean the pellet tank, proceed as follows:

Step	Action
1	Periodically remove the wood sawdust accumulated on the bottom of the tank, using a vacuum cleaner.

Extraction duct cleaning

Periodically check that the extraction duct is free from obstructions (dust, animal hair ...) and remove them if necessary.

Extraordinary maintenance



Maintenance operations must be carried out with the stove cold and with the power supply disconnected.



Extraordinary maintenance activities must be carried out by staff from the Authorised Assistance Centre.



Do not wait for components to be deteriorated by use before proceeding with their replacement. Replace a worn component before it is completely broken to prevent any damage caused by sudden component breakage.

Parts / frequency	1 Season
Deep combustion chamber cleaning	•
Door gasket	•
Chimney	•
Smoke conduit	•

Schedule the above extraordinary maintenance activities with the Authorised Assistance Centre.



Deep combustion chamber cleaning




This operation must be carried out by a Ravelli Assistance Centre.




Schedule this type of cleaning with the Ravelli Assistance Centre.

To clean the combustion chamber, proceed as described below:

After cleaning the combustion chamber, it is advisable to proceed with the cleaning of the inspection hatches as indicated in the paragraph "Smoke duct cleaning".







Rev.0 09/07/2025

Use and maintenance manual Circular



RAVELLI

Pag.54

Checking the seals



This operation must be carried out by a Ravelli Service Centre. Plan this type of cleaning with the Ravelli Service Centre.

When thoroughly cleaning the stove, the authorised technician must check that the gaskets of

- port
- hatches

are intact. If not, they will have to be replaced.

Smoke conduit cleaning




This operation must be carried out by a Ravelli Assistance Centre. Schedule this type of cleaning with the Ravelli Assistance

The stove is equipped with some hatches for cleaning the internal smoke ducts.

To clean the smoke ducts, proceed as described below:

	′ 1
Step	Action
1	Remove the side panel and vermiculites (see previous paragraph)
2	Open the side hatch
3	Open the lower hatches
4	Clean the ashes, eventually use a brush or similar and reassemble everything. Note: the hatches are equipped with gaskets, therefore, before reassembling them, make sure that the gaskets are not worn.

Note: The operation must be carried out when the stove is cold, using an ash vacuum cleaner.



Pag.55



Use and maintenance manual Circular

TROUBLESHOOTING

The appliance does not work

- Closely follow the directions in the dedicated chapter of this manual;
- make sure that the air intake duct is not obstructed;
- make sure that the smoke evacuation system is clean and not obstructed;
- make sure the chimney is sized for the appliance power;
- make sure that the air intake in the room is clear of any obstructions and that there are no other combustion appliances or extraction hoods that create a vacuum in the room;

Difficult lighting

- Closely follow the directions in the dedicated chapter of this manual;
- make sure that the air intake duct is not obstructed;
- make sure that the smoke evacuation system is clean and not obstructed;
- make sure the chimney is sized for the appliance power;
- make sure that the air intake in the room is clear of any obstructions and that there are no other combustion appliances or extraction hoods creating a vacuum in the room.

Smoke leakage

- Check the draught of the chimney;
- check whether the seals on the door, drawer and smoke evacuation system are intact;
- make sure there is no ash obstructing the primary air flow grille.

The glass gets dirty easily

- Only use recommended fuels;
- check the draught of the chimney.

Downtime (end of season)

At the end of every season we recommend vacuuming out any ash and dust that may still be inside. It is advisable to let the pellets burn out in the tank so that the pellet remains and sawdust can be vacuumed from the bottom and from the screw.

Disconnect the appliance from the power supply.

With thermo-stove or boiler, it is not necessary to empty it of water, but it is advisable to close the shut-off valves at the inlet and outlet for prolonged downtime.

DISPOSAL AT END OF SERVICE LIFE

Warnings for the correct disposal of the product

Demolition and disposal of the appliance is under the exclusive liability and responsibility of the owner who must do so in accordance with the laws in force in the country of installation pertaining to safety, respect and protection of the environment.

At the end of its service life, the product must not be disposed of as household waste. It can be taken to designated separate waste collection centres run by local administrations or to dealers who offer this service.

Disposing of the product as sorted waste avoids any negative consequences on the environment and health deriving from unsuitable disposal and it recovers the materials that the stove is composed of in order to save considerable energy and resources.

The following table and relative exploded view (image for illustrative purposes only) to which it refers, highlights the main parts that can be found in the device and the instructions for their correct separation and disposal at the end of their service life.

In particular, electric and electronic parts must be separated and disposed of at centres authorised for such activities, pursuant to directive WEEE 2012/19/EU and its national transpositions.

A EXTERNAL CLADDING	If present, dispose of it according to the material it is made of: - Metal - Glass - Tiles or ceramic - Stone - Wood
B DOOR GLAZING	If present, dispose of it according to the material it is made of: - Glass-ceramics (fire door): dispose of with inert or mixed waste - Tempered glass (oven door): dispose of in glass
C INTERNAL CLADDING	If present, dispose of it according to the material it is made of: - Metal - Refractory materials - Insulation panels - Vermiculite - Insulation, vermiculite and refractory materials that come into contact with the flame or exhaust gases (dispose of in mixed waste)

EN


Rev.0 09/07/2025

Use and maintenance manual Circular



Pag.56

D ELECTRICAL AND ELECTRONIC COMPONENTS	- Cables - Motors - Fans - Circulators - Displays - Sensors - Spark plugs - Electronic boards - Batteries Dispose of separately at authorised centres, in accordance with WEEE 2012/19/EU and its national transposition
E METAL STRUCTURE	Dispose of separately in metal
F NON-RECYCLABLE COMPONENTS	- Gaskets - Rubber, silicone or fibre hoses, plastics Dispose of in mixed waste





TECHNICAL DATA

(in accordance with EN 16510-1:2022, EN 16510-2-6:2022)

		UNIT OF MEASURE	Circular 9 CX	Circular 7 CX
Туре	Product classification		CM50	CM50
	Environmental quality class	*	5	5
	Energy efficiency class	2 2	A++	A+
EEI	Energy efficiency index		131	126
	Fuel	Wood pellets Ø6		
P _{in}	Power introduced Red Nom.	kW	3,1 - 8,9	3,1 - 7
P _{part} - P _{nom}	Power output Red Nom.	kW	2,9 - 8,2	2,9 - 6,5
η _{part} -η _{nom}	Efficiency Red Nom.	%	92 - 92	92 - 94
	Hourly pellet consumption Red Nom.	kg/h	0,8 - 1,83	0,8 -1,44
	Autonomy min max.	h	7 - 18	10 -18
	Heating volume *	m3	145 - 225	145 - 185
CO _{part} -CO _{nom}	CO at 13% di O2	mg/m3	187 - 78	187 - 59
OGC part - OGC nom	OGC at 13% O2	mg/m3	2 - 4	2-1
NO _{x part} - NO _{x nom}	NOX at 13% O2	mg/m3	145 - 96	145 - 94
PM part - PM nom	PM at 13% O2	mg/m3	9 - 14	9 - 13
T _{s part}	Flue gas temperature Red.	°C	121	121
T _{s nom}	Temperature in the flue pipe at nominal output	°C	164	138
T class	Minimum chimney designation		T200 G	T200 G
m _{chim}	Maximum flue load that the stove can support	kg	0	0
Ø _{f,g part} -Ø _{f,g nom}	Flue flow rate	g/s	3 - 5	3 - 3,6
p _{part} - p _{nom}	Min. draught	Pa	10 - 10	10 - 9
E, f	Power supply	V - Hz	230 - 50	230 - 50
W _{max}	Max. electrical power consumption	W	320	320
el _{min} - el _{max}	Electrical power in operation Red Nom.	kW	0,010 - 0,024	0,010 - 0,024
el _{SB}	Electric power in stand-by	KW	0,003	0,003
d _{in}	Ø combustion air intake pipe	mm	130 Coax / 50	130 Coax / 50
d _{out}	Ø smoke outlet pipe	mm	80	80
	Tank capacity	kg	14	14
η _s	Seasonal energy efficiency	%	89,7	84
CON/INT	Continuous operation (CON) / Intermittent operation (INT)	CON		
	Type of room temperature control	With electronic room temperature control and weekly timer		
	Other control options	With remote control option		

Use and maintenance manual Circular

The data shown are indicative and not binding and may vary depending on the type of pellet used. Ravelli reserves the right to make any changes in order to improve product performance.

 $^{^*}$ Values calculated for an average insulated building (35 W/m3, Climate Zone E) and for a non-insulated building (55 W/m3, Climate Zone E).



ITA-Informazioni per la gestione di rifiuti di apparecchiature elettriche ed elettroniche contenenti pile e accumulatori

Questo simbolo che appare sul prodotto, sulle pile, sugli accumulatori oppure sulla loro confezione o sulla loro documentazione, indica che il prodotto e le pile o gli accumulatori inclusi al termine del ciclo di vita utile non devono essere raccolti, recuperati o smaltiti assieme ai rifiuti domestici.

Una gestione impropria dei rifiuti di apparecchiature elettriche ed elettroniche, di pile o accumulatori può causare il rilascio di sostanze pericolose contenute nei prodotti. Allo scopo di evitare eventuali danni all'ambiente o alla salute, si invita l'utilizzatore a separare questa apparecchiatura, e/o le pile o accumulatori inclusi, da altri tipi di rifiuti e di consegnarla al centro comunale di raccolta. È possibile richiedere al distributore il ritiro del rifiuto di apparecchiatura elettrica ed elettronica alle condizioni e secondo le modalità previste dal D.Lgs. 49/2014.

La raccolta separata e il corretto trattamento delle apparecchiature elettriche ed elettroniche, delle pile e degli accumulatori favoriscono la conservazione delle risorse naturali, il rispetto dell'ambiente e assicurano la tutela

della salute.

Per ulteriori informazioni sui centri di raccolta dei rifiuti di apparecchiature elettriche ed elettroniche, di pile e accumulatori è necessario rivolgersi alle Autorità pubbliche competenti al rilascio delle autorizzazioni.

ENG-Information for management of electric and electronic appliance waste containing batteries or accumulators

This symbol, which is used on the product, batteries, accumulators or on the packaging or documents, means that at the end of its useful life, this product, the batteries and the accumulators included must not be collected, recycled or disposed of together with domestic waste.

Improper management of electric or electronic waste or batteries or accumulators can lead to the leakage of hazardous substances contained in the product. For the purpose of preventing damage to health or the environment, users are kindly asked to separate this equipment and/or batteries or accumulators included from other types of waste and to arrange for disposal by the municipal waste service It is possible to ask your local dealer to collect the waste electric or electronic appliance under the conditions and following the methods provided by national laws transposing the Directive 2012/19/EU.

Separate waste collection and recycling of unused electric and electronic equipment, batteries and accumulators helps to save natural resources and to guarantee that this waste is processed in a manner that is safe for health and the environment.

For more information about how to collect electric and electronic equipment and appliances, batteries and accumulators, please contact your local Council or Public Authority competent to issue the relevant permits.

FRA-Informations relatives à la gestion des déchets d'appareils électriques et électroniques contenant des piles et des

Ce symbole présent sur le produit, sur les piles, sur les accumulateurs, sur l'emballage ou sur la documentation de référence, indique que le produit et les piles ou les accumulateurs ne doivent pas être collectés, récupérés ou éliminés avec les déchets domestiques au terme de leur vie utile.

Une gestion impropre des déchets d'équipements électriques et électroniques, des piles ou des accumulateurs peut causer la libération de substances dangereuses contenues dans les produits. Pour éviter d'éventuelles atteintes à l'environnement ou à la santé, on invite l'utilisateur à séparer cet appareil, et / ou les piles ou les accumulateurs, des autres types de déchets et de le confier au service municipal de collecte. On peut demander au distributeur de prélever le déchet d'appareil électrique ou électronique aux conditions et suivant les modalités prévues par les normes nationales de transposition de la Directive 2012/19/UE.

La collecte sélective et le traitement correct des appareils électriques et électroniques, des piles et des accumulateurs, favorisent la conservation des ressources naturelles, le respect de l'environnement et assurent la protection de la santé.

Pour tout renseignement complémentaire sur les modalités de collecte des déchets d'appareils électriques et électroniques, des piles et des

Pour tout renseignement complémentaire sur les modalités de collecte des déchets d'appareils électriques et électroniques, des piles et des accumulateurs, il faut s'adresser aux Communes ou aux Autorités publiques compétentes pour la délivrance des autorisations.

NLD-Informatie voor het beheer van afgedankte elektrische en elektronische apparatuur die batterijen en accu's bevat

Dit symbool, dat op het product, op batterijen, op accu's, op de verpakking of in de documentatie ervan staat, geeft aan dat het product en de batterijen of accu's aan het einde van de gebruiksduur niet samen met het huishoudelijke afval mogen worden ingezameld of verwijderd.

Een onjuist beheer van afgedankte elektrische en elektronische apparatuur, batterijen of accu's kan leiden tot het vrijkomen van gevaarlijke stoffen in de producten. Om schade aan het milieu of aan de gezondheid te voorkomen, wordt de gebruiker aangemoedigd om deze apparatuur en/of de meegeleverde batterijen of accu's van andere soorten afval te scheiden en af te leveren aan de gemeentelijke ophaaldienst. Het is mogelijk om de distributeur te vragen om de afvalinzameling van elektrische en elektronische apparatuur uit te voeren volgens de voorwaarden en de voorschriften die zijn vastgelegd in de nationale bepalingen ter uitvoering van Richtlijn 2012/19/EU.

De gescheiden inzameling en correcte behandeling van elektrische en elektronische apparatuur, batterijen en accu's bevorderen het behoud van natuurlijke hulpbronnen, respect voor het milieu en zorgen voor de bescherming van de gezondheid.

Voor meer informatie over de inzameling van afgedankte elektrische en elektronische apparatuur, batterijen en accu's is het noodzakelijk om contact op te nemen met de gemeenten of de bevoegde overheidsinstanties.

DEU-Informationen für die Entsorgung von elektrischen und elektronischen Altgeräten, die Batterien und Akkus enthalten

Dieses Symbol auf dem Produkt, auf den Batterien, auf den Akkus, auf deren Verpackung oder in deren Unterlagen weist darauf hin, dass das Produkt und die Batterien oder Akkus am Ende ihrer Lebensdauer nicht zusammen mit dem normalen Hausmüll gesammelt, verwertet oder entsorgt werden dürfen.

Eine unsachgemäße Entsorgung von elektrischen und elektronischen Altgeräten, sowie von Batterien oder Akkus kann zur Freisetzung gefährlicher Stoffe im Produkt führen. Um mögliche Umwelt- oder Gesundheitsschäden zu vermeiden, wird der Benutzer aufgefordert, dieses Gerät bzw. die Batterien oder Akkus von anderen Abfallarten zu trennen und der kommunalen Sammelstelle zu übergeben. Außerdem ist es möglich, den Händler um die Rücknahme der elektrischen und elektronischen Altgeräte unter den in den nationalen Vorschriften zur Umsetzung der Richtlinie 2012/19/EU vorgesehenen Bedingungen zu bitten.

Die getrennte Sammlung und die ordnungsgemäße Verwertung von elektrischen und elektronischen Altgeräten, Batterien und Akkus fördert die Erhaltung der natürlichen Ressourcen, respektiert die Umwelt und gewährleistet den Schutz der Gesundheit.

Für weitere Informationen zur Sammlung von elektrischen und elektronischen Altgeräten, Batterien und Akkus wenden Sie sich bitte an die für die Erteilung von Genehmigungen zuständigen Kommunen oder Behörden.





ESP-Información para la gestión de residuos de aparatos eléctricos y electrónicos con pilas y

Este símbolo que aparece en el producto, en las pilas, los acumuladores o en su embalaje o su documentación indica que el producto y las pilas o acumuladores que contiene, al final de su vida útil, no deben recogerse, recuperarse o desecharse junto con los residuos domésticos.

Una gestión inadecuada de los residuos de aparatos eléctricos y electrónicos, pilas o acumuladores podría provocar la liberación de sustancias peligrosas contenidas en los productos. Para evitar posibles daños para el medio ambiente o la salud, se recomienda al usuario que separe este aparato y/o las pilas o acumuladores que contiene de otros tipos de residuos y lo entregue al servicio municipal encargado de la recogida. Se puede solicitar al distribuidor la recogida de los residuos de aparatos eléctricos y electrónicos en las condiciones y de acuerdo con las modalidades establecidas por las normas nacionales de transposición de la Directiva 2012/19/UE.

La recogida diferenciada y el tratamiento correcto de los aparatos eléctricos y electrónicos, de las pilas y los

acumuladores favorecen la conservación de los recursos naturales, el respeto del medio ambiente y garantizan la protección de la salud.

Para obtener más información sobre las modalidades de recogida de los residuos de aparatos eléctricos y electrónicos, de las pilas y los acumuladores es necesario acudir a los ayuntamientos o las autoridades públicas competentes para la concesión de autorizaciones.

PRT-Informações sobre a gestão dos resíduos de equipamentos elétricos e eletrónicos contendo pilhas e acumuladores

Este símbolo no produto, pilhas, acumuladores ou respetiva embalagem ou documentação indica que, no final do seu ciclo de vida útil, o produto e as pilhas ou acumuladores incluídos não devem ser recolhidos, recuperados nem eliminados conjuntamente com o lixo doméstico.

Uma gestão imprópria dos resíduos de equipamentos elétricos e eletrónicos, pilhas ou acumuladores pode causar a libertação de substâncias perigosas contidas nos produtos. A fim de evitar eventuais danos para o ambiente ou para a saúde, o utilizador é convidado a separar este equipamento e/ou pilhas ou acumuladores incluídos de outros tipos de resíduos e a depositá-los no serviço municipal de recolha de lixo. É possível requisitar a recolha dos resíduos de equipamentos elétricos e eletrónicos pelo distribuidor segundo as condições e modalidades previstas pelas normas nacionais de transposição da diretiva 2012/19/UE.

A recolha separada e o correto tratamento dos equipamentos elétricos e eletrónicos e respetivas pilhas e acumuladores favorecem a conservação dos recursos naturais, o respeito do ambiente e a proteção da saúde.

Para mais informações sobre as modalidades de recolha dos resíduos de equipamentos elétricos e eletrónicos, pilhas e acumuladores, dirija-se à sua Câmara Municipal ou à autoridade pública competente para a emissão das autorizações.

GRC-Πληροφορίες για τη διαχείριση αποβλήτων ηλεκτρικού και ηλεκτρονικού εξοπλισμού, μπαταριών και συσσωρευτών

Αυτό το σύμβολο που εμφανίζεται στο προϊόν, στις μπαταρίες, στους συσσωρευτές στη συσκευασία ή στα έγγραφα υποδεικνύει ότι το προϊόν στο τέλος της ωφέλιμης ζωής του δεν πρέπει να συλλέγεται, να ανασύρεται ή να απορρίπτεται με τα οικιακά απορρίμματα.

Ο ακατάλληλος χειρισμός των αποβλήτων ηλεκτρικού και ηλεκτρονικού εξοπλισμού, μπαταρίες ή συσσωρευτές μπορεί να οδηγήσει στην απελευθέρωση επικίνδυνων ουσιών που περιέχονται στο προϊόν. Προκειμένου να αποφευχθεί τυχόν μόλυνση στο περιβάλλον ή ασθένεια, ο χρήστης ενθαρρύνεται να διαχωρίσει αυτόν τον εξοπλισμό ή/και τις μπαταρίες ή τους συσσωρευτές που περιλαμβάνονται από άλλα είδη αποβλήτων και να το παραδώσει στην υπηρεσία δημοτικών συλλογών. Είναι δυνατόν να ζητηθεί από τον διανομέα η συλλογή αποβλήτων ηλεκτρικού και ηλεκτρονικού εξοπλισμού που πρέπει να πραγματοποιηθεί σύμφωνα με τους όρους και με τις διαδικασίες που θεσπίζονται από τις εθνικές διατάξεις εφαρμογής της οδηγίας 2012/19/ΕΕ.

Η χωριστή συλλογή και η σωστή επεξεργασία ηλεκτρικού και ηλεκτρονικού εξοπλισμού, μπαταριών και συσσωρευτών ευνοούν τη διατήρηση των φυσικών πόρων, τον σεβασμό για το περιβάλλον και την προστασία της υγείας.

Για περισσότερες πληροφορίες σχετικά με τον τρόπο συλλογής των αποβλήτων ηλεκτρικού και ηλεκτρονικού εξοπλισμού, μπαταριών και συσσωρευτών είναι απαραίτητο να επικοινωνήσετε με τους δήμους ή τις δημόσιες αρχές που είναι αρμόδιες για την έκδοση των αδειών.

DNK-Informationer til behandling af affald fra elektriske og elektroniske udstyr der indeholder batterier og akkumulatorer

Dette symbol, der vises på produktet, på batterierne eller på akkumulatorerne, på indpakningen eller i dokumentationen, angiver at selve produkt, nå dets levetid er opbrugt, ikke skal opsamles, genvindes eller bortskaffes sammen med normalt husholdningsaffald.

En ukorrekt behandling af affald fra elektriske eller elektroniske udstyr, af batterier og akkumulatorer, risikerer at udlede farlige stoffer indeholdt i produktet. For at forebygge ventuelle skader for miljøet eller sundheden, bedes brugeren om at behandle dette udstyr, og/eller de medfølgende batterier eller akkumulatorerne separat fra andre affaldstyper, og at levere det til det kommunale opsamlingscenter, eller at anmode leverandøren om opsamling, i henhold til forskrifterne, der er angivet i de nationale forordninger til gennemførelse af Direktivet 2012/19/EF.

Den separate opsamling og genvinding af de nedslidte elektriske og elektroniske udstyr, af batterierne og af akkumulatorerne, fremmer bevarelsen af de naturlige ressourcer, og sikrer at dette affald behandles ved at tage hensyn til miljøets og sundhedens varetagelse.

Til yderligere informationer angående opsamling af affald fra elektriske og elektroniske udstyr, af batterier og akkumulatorer, er det nødvendigt at rette henvendelse til Kommunerne eller til de ansvarlige myndigheder til udstedelse af bemyndigelserne.

POL-Informacje dotyczące zarządzania odpadami sprzętu elektrycznego i elektronicznego zawierającego baterie i akumulatory

Niniejszy symbol znajdujący się na produkcie, bateriach, akumulatorach, na ich opakowaniu lub na dokumentacji, wskazuje, że produkt, baterie lub akumulatory po zakończeniu okresu użytkowania nie mogą być zbierane, odzyskiwane lub utylizowane wraz z odpadami komunalnymi. Niewłaściwe postępowanie ze zużytym sprzętem elektrycznym i elektronicznym, bateriami lub akumulatorami może powodować uwolnienie niebezpiecznych substancji zawartych w produktach. Celem uniknięcia jakichkolwiek szkód dla środowiska lub zdrowia, użytkownik proszony jest o odseparowanie niniejszego sprzętu i/lub dołączonych baterii lub akumulatorów od innych rodzajów odpadów i dostarczenia go do miejskiego punktu zbierania odpadów. Możliwe jest zwrócenie się z prośbą do dystrybutora o odebranie odpadów sprzętu elektrycznego i elektronicznego, na warunkach i zgodnie z procedurami ustanowionymi przez przepisy krajowe transponujące dyrektywę 2012/19/UE.

Oddzielna zbiórka i prawidłowe przetwarzanie sprzętu elektrycznego i elektronicznego, baterii i akumulatorów sprzyja ochronie zasobów naturalnych, poszanowaniu środowiska i zapewnieniu ochrony zdrowia.

Aby uzyskać więcej informacji dotyczących zbiórki zużytego sprzętu elektrycznego i elektronicznego, baterii i akumulatorów, należy skontaktować się z władzami miejskimi lub organami publicznymi odpowiedzialnymi za wydawanie zezwoleń.

SVN-Informacije o ravnanju z odpadno električno in elektronsko opremo, ki vsebuje baterije in akumulatorje

Ta simbol, ki se nahaja na izdelku, baterijah, akumulatorjih ali na njihovi embalaži ali v dokumentaciji, označuje, da se po izteku življenjske dobe izdelka ter baterij ali akumulatorjev, ki jih izdelek vsebuje, ne sme zbirati, predelati ali odstranjevati skupaj z odpadki iz gospodinjstev.

Neprimerno ravnanje z odpadno električno in elektronsko opremo, baterijami ali akumulatorji lahko povzroči izpust nevarnih snovi, ki jih vsebujejo izdelki. Da bi preprečili morebitne škodljive vplive na okolje ali zdravje, uporabnike pozivamo, da tovrstno opremo in/ali baterije ali akumulatorje, ki jih oprema vsebuje, ločujejo od drugih vrst odpadkov ter jih oddajo občinski službi za zbiranje odpadkov. Od distributerja lahko zahtevate prevzem odpadne električne in elektronske opreme pod pogoji in na načine, skladno s katerimi je bila Direktiva 2012/19/EU prenesena v nacionalno zakonodajo.

Ločevanje in ustrezna obdelava električnih in elektronskih naprav, baterij in akumulatorjev pripomoreta k ohranjanju naravnih virov, spoštovanju okolja ter zagotavljata varovanje zdravja.

Za dodatne informacije o načinih zbiranja odpadne električne in elektronske opreme, baterij in akumulatorjev se obrnite na občine ali na javne organe, ki so pristojni za izdajanje dovoljenj.



Aico S.r.l.

Headquarter

Via Consorzio Agrario, 3 - 25032 Chiari (BS) - Italy

Research and Development Centre

Viale del commercio 12/a - 37135 Verona (VR) - Italy

T. + 39 030 7402939 info@ravelligroup.it

FB Ravellifuocointelligente IG ravellistufe

www.ravelligroup.it

Aico S.r.l. does not assume any responsibility for any errors in this booklet and considers itself free to make any variations to the features of its products without notice.